


# MAXHUB WB05

## User Manual




MAXHUB

## ◆ Setup guidance

### A. Connect to device hotspot;


1. Connect to the hotspot displayed at the bottom of the screen;




2. Log in to the Admin address;

3. Select a language;


4. Select your location;




5. After a restart, continuing setting up by clicking "Set up now";



6. You can set a password when you first log in or choose to skip;





## 7. Setting up your network or connecting to Wi-Fi;




## 8. Display Settings:

- Set the HDMI output signal to show always or only when screening.
- Select the desired resolution and frame rate.
- Choose the appropriate overscan level.;




### 9. Wallpaper Settings:


- Choose whether to display the screen sharing code during screen sharing or not.
- Select either the default image or customize one from your device as wallpaper.
- Decide what guidance you need to show on the wallpaper;




### 10. Setting the boot and shutdown time and configuring the repetition:





11. To change the language;



12. To change the date and time or set it for auto-synchronization;



**13. To reset the WB05 ;****14. To check the firmware version of the WB05 ;**


## B. Connect to a external Mouse for configuration

1. Clicking Begin;



2. Select a language;

3. Select your location and wait for 1-2mins restart



4. Left-Click Top left for 4 times, will enter A)6.)



5. Following A)7-14.)

## ◆ Screen sharing


### A. Computer (MAXHUB Share)

1. Ensure that your computer is connected to the same Wi-Fi network as the WB05 or connected to the Hotspot from the WB05;

2. Launch MAXHUB Share

Could be downloaded from <https://www.maxhub.com/en/support/?#trigger-download-center>

3. Enter the Screen Sharing Code Shown on the Wallpaper



## B. Computer(Screen sharing dongle)

1. Pairing the screen sharing dongle with WB05 and plug in to personal Laptop;
2. Push the button of the Screen sharing dongle to sharing screen;



3. If you have multiple device to sharing screen, press and hold the button of a Screen sharing dongle to split the screen.

## C. Mobile Phone

1. Ensure that your Phone is connected to the same Wi-Fi network as the WB05 or connected to the Hotspot from the WB05;
2. Launch MAXHUB Share on your phone;
3. Input the Code or scan the QR code on the WB05 wallpaper.




## ◆ BYOM


### A. MAXHUB Share



1. Connect to the WB05 by MAXHUB Share software on personal laptop following the previous procedures;
2. Connect the MAXHUB UC products to the WB05 using the USB interface;
3. Turn on and select the MAXHUB Product you want to use on the MAXHUB SHARE of personal laptop




4. Launch a meeting on video meeting platform and select Sharing audio and Sharing camera as audio and video device for wireless use with the MAXHUB UC peripherals



## B. WT13M(not available in some zones)

1. Connect the WB05 by screen sharing dongle to the personal Laptop following the previous procedures;
2. Connect the MAXHUB UC products to the WB05 using the USB interface;
3. Launch a meeting on video meeting platform and select M-media as audio and video device for wireless use with the MAXHUB UC peripherals.



# MAXHUB

